

Playback: I can't get the selected output variables to display in the Video Creator window.

Q: I can't get the selected output variables to display in the Video Creator window. I have them turned on and selected as I normally do, but don't see them. Help!

A: It sounds like you adjusted the Camera properties for the Near Clipping Plane to a distance just beyond where the Key Results display is positioned in the Video Creator. That display is an object which you can move around the viewer to the position best suited for your simulation movie. As an object, it requires the viewer clipping plane to be set close enough to prevent the variable display from being 'clipped' from the camera view. If you change the near clipping plane back closer to the camera, you will find that the results will be displayed as expected.

Unique solution ID: #1093

Author: EDC

Last update: 2013-07-17 01:31