

EDCRASH TUTORIAL

Chapter


5

This tutorial illustrates a very common use of EDCRASH, that is, to estimate the vehicle impact velocities from accident scene and vehicle damage measurements. This tutorial is continued in the EDSMAC(4) Tutorial, wherein the initial vehicle velocities are used to simulate the crash. You may wish to review that tutorial after finishing this one.

Like all EDCRASH events, the procedure involves the following basic steps:


- Create the vehicle(s)
- Create the environment
- Execute the EDCRASH event
- Review the EDCRASH output reports


This basic procedure is described in detail in this tutorial.


 **NOTE:** *It is assumed that HVE-2D or HVE is up and running, and that the user is familiar with its basic features, such as using dialogs and viewers, as well as the Editors. The purpose of this tutorial is to illustrate those features while setting up and executing an EDCRASH event.*

Getting Started

As in other tutorials, before we get started with our current tutorial, let's set the user options so we're all starting on the same page.


 **NOTE:** In HVE-2D, all options simply affect the appearance in a viewer during Event or Playback mode.

 However, in HVE, `AutoPosition` affects the data used in the analysis. For example, if `AutoPosition` is On, the vehicle position conforms to the local surface; otherwise, the position is set by the Position/Velocity dialog. Obviously, the resulting difference in initial conditions could substantially change the event.

 **NOTE:** Some of the following options are "Toggles" that switch between two different modes. Make sure these options are set correctly.

To set the initial user options, choose the following from the Options Menu:

- ON: Show Key Results
- OFF: Show Axes
- ON: Show Contacts
- OFF: Show Velocity Vectors
- ON: Show Skidmarks
- OFF: Show Targets
- ON: `AutoPosition`
- Units equals *S.I.*

 **NOTE:** As we'll see when we create our environment, our EDCRASH Tutorial studies a crash that took place in Australia; thus we require metric units.


- Render Options:
 - Show Humans as *Actual*
 - Show Vehicles as *Actual*
 - Phong Render Method
 - Complexity equals *Object*
 - Render Quality equals 5
 - Texture Quality equals 1
 - Anti-aliasing equals 1

The remaining options will automatically initialize to their default conditions. We're now ready to proceed with the tutorial.

Creating the Vehicles

Let's add the vehicles to our case. The first vehicle is a white, 1996 Ford Escort 2-Door Hatchback; the second vehicle is a dark red 1995 Nissan Sentra 4-door Sedan. Let's add the first vehicle:

- If the Vehicle Editor is not the current editor, choose *Vehicle Mode*. The Vehicle Editor is displayed.
- Click *Add New Object*. The Vehicle Information dialog is displayed. The Vehicle Information dialog allows the user to select the basic vehicle attributes according to *Type*, *Make*, *Model*, *Year* and *Body Style*.

 **NOTE:** The Vehicle Information dialog also allows you to edit the *Driver Location*, *Engine Location*, *Number of Axles* and *Drive Axle(s)*. These options are already assigned for each vehicle and need not be edited in our tutorial.

- Using the option buttons, click each button to choose the following vehicle from the database:
 - Type = *Passenger Car*
 - Make = *Ford*
 - Model = *Escort*
 - Year = *1991-1996*
 - Body Style = *2-Door Hatchback*
 - Driver Location = *Right*
- Click *OK* to add *Ford Escort 2-Dr Hatchback* to the Active Vehicles list.

Next, let's add the Nissan Sentra:

- Click *Add New Object*. The Vehicle Information dialog is displayed.
- Using the option buttons, click each button to choose the following vehicle from the database:
 - Type = *Passenger Car*
 - Make = *Nissan*
 - Model = *Sentra*
 - Year = *1995-1999*
 - Body Style = *4-Door*
 - Driver Location = *Right*
- Click *OK* to add *Nissan Sentra 4-Dr* to the Active Vehicles list.

We now have the vehicles required for our study, as shown in Figure 5-1.





Figure 5-1 *Ford Escort 2-Dr Hatchback* (above) and *Nissan Sentra 4-Dr* (below).

Figure 5-2 Vehicle Color dialog, used for assigning the vehicle color.



Editing the Vehicles


Next, we'll edit the vehicles to change their color and weight. In addition, we'll change the stiffness of the Nissan Sentra, using values derived from our initial reconstruction analysis.

Start by changing the color of the Ford Escort:

- Click on *Ford Escort 2-Dr Hatchback* in the Active Vehicles list, making it the current vehicle. The Ford Escort is now displayed in the Vehicle Editor.
- Click on the CG and choose *Color*. The Vehicle Color dialog is displayed (see Figure 5-2), showing the vehicle's current color (the small black square, or *hot spot*, in the color wheel) and intensity (the arrow in the intensity slider). Click on the hot spot and drag it to the center of the blue area. To lighten the vehicle, click on the intensity slider and drag it to the far right end.

 **NOTE:** The color chip on the left shows the current color.

- When the color is to your liking, press the *Close* button to apply the new vehicle color.

 **NOTE:** The vehicle's apparent color may be slightly misleading because the vehicle is translucent when displayed in the Vehicle Editor. The actual color will be used whenever the vehicle is displayed during Event and Playback mode.






Figure 5-3 Vehicle Inertias dialog, used for editing the current weight and yaw inertia (roll and pitch inertias are not used by EDCRASH).


Next, let's change the Escort's weight. Perform the following steps:

- Click on the CG and choose *Inertias*. The Inertias dialog is displayed (see Figure 5-3), and we're ready to change the vehicle's weight.

 **NOTE:** The vehicle's roll, pitch and yaw moments of inertia are also displayed in the Inertias dialog; however, only the yaw inertia is used by the 3-DOF EDCRASH calculations.

- In the *Total Weight* text field, replace the existing weight, 10283 Newtons, with the measured value, 11037 Newtons.

 **NOTE:** The weight is entered as a force (Newtons). Mass units (kg) are calculated and displayed.


 **NOTE:** The dialog might display 10283.5, or similar number because the weight is actually divided by the current gravity constant and stored as mass. Extra precision results when the mass is multiplied by the current gravity constant and redisplayed.

- Press *OK* to accept the weight value.

The Ford Escort is now ready for use in our tutorial. Using the viewer thumb wheels or mouse, zoom in or out on the vehicle or translate the vehicle in the viewer X or Y directions

Now, let's change the color, weight and stiffness of the Nissan Sentra:


- Click on *Nissan Sentra 4-Dr* in the Active Vehicles list, making it the current vehicle. The Nissan Sentra is now displayed in the Vehicle Editor.
- Click on the CG and choose *Color*. The Vehicle Color dialog is displayed. The vehicle's color is fine, but we need to darken it. To darken the vehicle, click on the intensity slider and drag it to the middle of the range.

 **NOTE:** *The color chip on the left shows the current color.*

- When the color is to your liking, press the *Close* button to apply the new vehicle color.

Next, let's change the Nissan's weight:


- Click on the CG and choose *Inertias*. The Inertias dialog is displayed.
- In the *Total Weight* text field, replace the existing weight, 10858 Newtons, with the measured value, 11282 Newtons.

 **NOTE:** *Again, the value displayed in the dialog may contain extra precision, for the reasons explained earlier.*

- Press *OK* to accept the weight value.

Finally, let's change the stiffness on the right side of the vehicle. An SAE moving barrier crash test (SAE J972) revealed the And B stiffness coefficients for the side of the vehicle were 245 N/cm and 50 N/cm², respectively. Let's enter the new values:

- Click on the right side surface icon (red sphere). The CG to Right Side dialog is displayed.
- Click *Stiffness*. The Stiffness Coefficients dialog for the right side surface is displayed, as shown in Figure 5-4 on the following page.

 **NOTE:** *The Vehicle Editor assumes the stiffness is uniform across the right side of the vehicle. If desired, we can add hard spots using the Damage Profile dialog during Event mode.*




Figure 5-4 Vehicle Stiffness dialog, used for editing the current A, B and Kv stiffness coefficients for the current surface. Note that EDCRASH allows the user to assign different stiffness values for the front, back and sides. By default, the stiffness is uniform on any side; however, hard spots may be assigned using the Event Editor (described later).

To edit the current A and B stiffness coefficients:

- Replace the current value in the A field with the calculated value, 245 N/cm. Then enter a new value for B, 50 N/cm².
- Click *OK* to update the stiffness coefficients.
- Click *OK* again to remove the CG to Right Side dialog.

The Nissan Sentra is now ready for use in our tutorial. Using the viewer thumb wheels, pan, zoom and look at the vehicle.


Note that, in HVE, the thumb wheels rotate the vehicle about the *viewer* axes, not the *vehicle* axes.

Now, we have both vehicles ready for our study.


Saving the Case

Now that we've created vehicles for our case, let's save the case file.


- Click on the *File* menu and choose *Save*. The Save-as File Selection dialog is displayed.

 **NOTE:** *The Save-as dialog is displayed because the case has not been saved previously, so we need to enter a filename.*

- Place the mouse cursor in the Case Title text field and enter `EDCRASH Tutorial, Visibility Study`.

 **NOTE:** *The Case Title is displayed as a heading on all printed output reports.*


- Place the mouse cursor in the Filename text field and enter `EdcrashTutorial`.
- Click *SAVE*. The current case data are saved in the `hve2d/supportFiles/case` subdirectory.

 **NOTE:** *Saving the file occasionally is a highly recommended practice.*


Creating the Environment

Now, let's add the environment:


- Choose *Environment Mode*. The Environment Editor is displayed.
- Click on *Add New Object*. The Environment Information dialog is displayed.
- Using the Location Database combo box, choose *Sydney, NSW, Australia*. The latitude (35.53.00S), longitude (151.10.00E) and GMT, hours from the prime meridian (+10) are displayed for the selected location.

 **NOTE:** *If Sydney were not included in your Location Database, you could add it simply by typing in the new location name, latitude, longitude and GMT.*

- Enter a name for the accident site, *Blind Intersection*.
- Edit the date and time of the incident we are studying, *7/23/99* and *1330*, respectively.
- Edit the angle from *true north* to the earth-fixed X axis in our environment, *-10* degrees.

 **NOTE:** *The Latitude, Longitude, GMT, Date/Time and angle from true north are used to position the sun in the scene. This is, of course, important because the sun is the primary light source for the scene.*

- To add the environment geometry file to our case, click on *Open*. The Environment Geometry File Selection dialog is displayed.
- Click on the *Files of Type* option list and choose *HVE Geometry Files (*.h3d)*. A list of environment geometry files using the .h3d file format is displayed in a list box.
- Double-click on *EdcrashEdsmacTutorial_2D.h3d* to choose the environment file and remove the dialog.

 **NOTE:** *HVE users should select the environment file named *EdcrashEdsmacTutorial.h3d*.*

- Press *OK*.




Figure 5-5 Appearance of the 2-D environment geometry used by HVE-2D users for the EDCRASH tutorial. HVE users will use a similar environment geometry, but with the enhancements of additional images of buildings and traffic controls included in the model.


The selected environment is added to our case and displayed in the Environment Viewer (see Figure 5-5). Use the viewer thumb wheels to view the scene.

Creating the Event

As mentioned at the outset, this EDCRASH tutorial describes a common application of EDCRASH, that is, to determine pre-impact vehicle velocities. This can be accomplished only when scene data (vehicle positions at impact and rest) are known. Fortunately, we have that data, owing to a splendid at-scene investigation. In addition, vehicle damage profiles are available from vehicle inspections.

To create the event, perform the following steps:


- Choose *Event Mode*. The Event Editor is displayed.
- Click on *Add New Object*. The Event Information dialog is displayed.
- Select *Ford Escort 2-Dr Hatchback* and *Nissan Sentra 4-Dr* from the Active Vehicles list. The vehicles are added to the Event Humans and Vehicles list.
- Select *EDCRASH* from the *Calculation Method* options list.
- Enter a name for the event, *Visibility Study*.

 **NOTE:** *The name of the calculation method will automatically be appended to the event name, thus the complete event name will become "EDCRASH, Visibility Study."*


- Press *OK* to display the event editor.

Now, we're ready to set up the event. Event set-up for EDCRASH involves the following three steps:

- **Position the Vehicles** - The minimum required vehicle positions are *Impact* and *Rest*. Vehicle positions at *Begin Braking*, *Point-on-curve* (POC) and *End-of-rotation* (EOR) are optional positions that may be assigned for each vehicle.

 **NOTE:** *If Impact and Rest positions are not assigned for both vehicles, impact speeds cannot be computed - it is physically impossible!*

- **Assign Wheel Data** - Wheel data (*% Wheel Lock-up*, *Steer Angle* and *Pre-impact Wheel Lock-up*) are required whenever scene data are supplied.
- **Assign Damage Profiles** - Vehicle damage profiles (*damage Width*, *Depth* and *Offset*) are optional for oblique collisions, but required for collinear collisions, where the momentum analysis is too sensitive to the scene data to be reliable.

 **NOTE:** *Even though damage profiles are not required for oblique collisions, they provide an excellent confirming analysis.*







Figure 5-6 Positioning the Ford Escort using the Event Editor. The manipulators can be used to *drag and drop* the vehicle into position. In the figure above, the Escort is being placed in its impact position on the environment model used in HVE.


Let's set up the Ford Escort. It skidded for a short distance before impact. Let's start by entering its *Begin Braking* position:

- Select *Ford Escort 2-Dr Hatchback* from the Event Humans & Vehicles list.
- Click *Set-up* from the menu bar and choose *Position/Velocity*. The *Impact* position for the Escort is displayed at the earth-fixed origin.
- Click on the Position/Velocity dialog's *Path Location* option list and choose *Begin Braking*. The Escort *Begin Braking* position is displayed at the earth-fixed origin.
- Click on the vehicle's X-Y manipulator, wait for it to turn bright yellow (indicating it has been selected), and drag it to its begin braking position, $X=18.0$ m, $Y=15.0$ m. In the Yaw field of the Position/Velocity dialog, replace the existing value with the correct heading angle for the start of braking, 180 degrees.

 **NOTE:** To select the X-Y manipulator, the viewer must be in *Pick* mode, as indicated by the highlighted arrow in the upper right corner of the viewer (see Figure 5-6).

 **NOTE:** If necessary, adjust the viewer by panning and dollying back (using the viewer controls) until you can see the entire intersection.

 **NOTE:** Be sure to keep the mouse button depressed while you drag the manipulators.


 **NOTE:** If you can't position the vehicle at the exact coordinates, you can simply enter the coordinates in the dialog (remember to press <Enter> after entering the data; otherwise the new values will not be used!).

Now let's position the Escort at its impact position:

- Click on the Position/Velocity dialog's *Path Location* option list and choose *Impact*. The Escort impact position is displayed at the earth-fixed origin.
- Click on the vehicle's X-Y manipulator (see Figure 5-6), wait for it to turn bright yellow (indicating it has been selected), and drag it to its impact position, X=6.0 m, Y=13.75 m. In the Yaw field of the Position/Velocity dialog, replace the existing value with the impact heading angle, 195.0 degrees.

Now, enter the sideslip angle at impact:

- Click the *Velocity Is Assigned* check box to allow velocity entries.
- Enter the impact sideslip angle, -4.35 degrees.

 **NOTE:** Although you could enter an impact velocity, EDCRASH would not use it; after all, it is EDCRASH's role to calculate impact speed!

Next, let's position the Escort at its rest position:

- Click on the *Path Location* option list and choose *Final/Rest*. The Escort is displayed at the earth-fixed origin.
- Click on the vehicle's X-Y manipulator, wait for it to turn bright yellow (indicating it has been selected), and drag it to its rest position, X=3.5 m, Y=12.75 m. In the Yaw field of the Position/Velocity dialog, replace the existing value with the rest heading angle, 230 degrees.




Figure 5-7 View of the scene after the Ford Escort has been positioned at its *Begin Braking*, *Impact* and *Rest* positions.

☞ **NOTE:** In HVE and HVE-2D, +230 degrees is *not* the same as -130 degrees because the relative magnitude between two angles implies the rotation direction! For example, if the impact heading angle is 180 degrees and the rest heading angle is 230 degrees, the change in heading angle between impact and rest is +50 degrees clockwise; if the rest heading angle is -130 degrees, the change in heading angle is -310 degrees and the direction of rotation is counter-clockwise.

☞ **NOTE:** If you can't position the vehicle at the exact coordinates, simply enter them in the dialog (in fact, it's often easier to directly enter the coordinates using the dialog).

Upon completion of this step, the Ford Escort should be displayed at its *Begin Braking*, *Impact* and *Rest* positions, as shown in Figure 5-7.

Next, let's enter the driver controls for the Ford Escort:

- Choose *Set-up* from the menu bar, select *Driver Controls*. The Driver Controls dialog is displayed.
- The *Wheel Data* page is displayed for the Ford Escort (Figure 5-8).




Figure 5-8 Wheel Data dialog for the Ford Escort.

According to our vehicle inspection, both front wheels were locked after impact by damage, while the rear wheels were free turning. Let's enter the appropriate values, first for the front wheels:

- Place the cursor in the Post Impact Percent Lock-up field for the right front wheel and enter 1.0. Enter the same value, 1.0, for the left front wheel.

Now the rear wheels:

- Place the cursor in the Percent Lock-up field for the right rear wheel and enter 0.01 (0.01/ μ slide). Enter the same value, 0.01, for the left rear wheel.

Table 5-1 Typical Wheel Lock-up Values [20].

Wheel Condition	Typical Range
No Damage, Free-rolling	0.01/ μ_{slide} to 0.02/ μ_{slide}
No Damage, Drive Wheel	0.10/ μ_{slide} to 0.15/ μ_{slide}
Damage	0.0 to 1.0

NOTE: For undamaged wheels, be sure to divide by the slide coefficient of friction, μ_{slide} , before entering the value for each wheel.

Next, let's enter the Percent Lock-up during pre-impact braking. Because the tires left skidmarks, we'll assume 100 percent braking:

- Place the text cursor in the Pre-impact Total Wheel Lock-up field and enter 1 . 0.

Finally, noting the vehicle rotated and skidded after impact, let's select that EDCRASH option:

- Click on the *Rot/Lat Skid* check box.
- Press *OK* to accept the wheel data.

The wheel data have now been assigned for the Ford Escort.

Let's conclude event set-up for the Escort by supplying a damage profile:

- Choose *Set-up* from the menu bar, select *Damage Profiles*. The Damage Profile dialog is displayed for the Ford Escort.

The Damage Profile dialog initially contains *None*, waiting for us to assign a CDC (Collision Deformation Classification; see HVE User's Manual, ref. 6.3):

- Replace *None* in the CDC field with 11FDEW3 and click *Apply*. The default damage profile is displayed according to the CDC.

Because we actually measured the damage profile during our vehicle inspection, let's enter the measured width, depth and offset:

- The default damage width, 169.42 cm, and offset, 0.00 cm, are acceptable.

We measured seven crush depths, so we have six crush zones:

- Click on the Damage Profile *Zones* option list and change the default value from 3 to 6.

Table 5-2 Crush depths for the front of the Ford Escort 2-Dr Hatchback.

Crush Depth No.	Crush Depth (cm)
1	75.0
2	60.0
3	50.0
4	45.0
5	40.0
6	40.0
7	45.0

NOTE: Front and rear crush depths are entered left-to-right.

- Enter the seven crush depths, beginning on the left end of the damage profile, according to Table 5-2.

 NOTE: Remember to press *Apply* after entering the crush depth values.

When completed, the Ford Escort appears as shown in Figure 5-9.

- Press *OK* to accept the assigned damage profile data.

Event set-up for the Ford Escort is now complete.

Let's set up the Nissan Sentra. We'll start by assigning its impact and rest positions:

- Select *Nissan Sentra 4-Dr* from the Event Editor's Event Humans and Vehicles list.
- Click *Set-up* from the menu bar and choose *Position/Velocity*. The *Impact* position for the Sentra is displayed at the earth-fixed origin.






Figure 5-9 Damage Profile dialog for the Ford Escort.

- Click on the vehicle's X-Y manipulator, wait for it to turn bright yellow (indicating it has been selected), and drag it to its impact position, $X=3.5$ m, $Y=1.3$ m. In the Yaw field of the Position/Velocity dialog, replace the existing value with the heading angle, -90 degrees. When finished, the Nissan Sentra will be positioned as shown in Figure 5-10.

 **NOTE:** Be sure to keep the mouse button depressed while you drag the manipulators.

 You may wish to enter the values directly in the Position/Velocity dialog.




Figure 5-10 Positioning the Nissan Sentra using the Event Editor. The manipulators can be used to *drag and drop* the vehicle into position. In the figure above, the Sentra is being placed in its impact position. Note the Ford Escort's rest position visually obstructs our positioning of the Nissan Sentra; this visual obstruction does not affect calculations.

Next, let's position the Nissan at its rest position:

- Click on the Position/Velocity dialog's *Path Location* option list and choose *Final/Rest*. The Sentra's rest position is displayed at the earth-fixed origin.
- Click on the vehicle's X-Y manipulator, wait for it to turn bright yellow (indicating it has been selected), and drag it to its rest position, $X=0.5$ m, $Y=2.25$ m. In the Yaw field of the Position/Velocity dialog, replace the existing value with the rest heading angle, 70 degrees.

☞ **NOTE:** Be sure to keep the mouse button depressed while you drag the manipulators.

☞ You may wish to enter the values directly in the Position/Velocity dialog.

☞ **NOTE:** In HVE and HVE-2D, +70 degrees is not the same as -290 degrees because the relative magnitude between two angles implies the rotation direction!

The Nissan's positions are now established. Let's enter the driver controls. In this case, there are no driver inputs, per se. However, after impact the vehicle coasts to rest, so we need to enter rolling resistances:


- Choose *Set-up* from the menu bar and select *Driver Controls*. The *Wheel Data* dialog is displayed.

According to our vehicle inspection, all the wheels were free turning (i.e., not locked by damage). Let's enter the appropriate values, first for the front wheels:

- Accept the default values for Percent Lock-up for Axle 1, Right Side and Left Side, 0.20 (0.15/ μ_{slide}).

Now the rear wheels:

- In the Percent Lock-up field for Axle 2, Right Side, enter 0.01 (0.01/ μ_{slide}). Enter the same value, 0.01, for the left rear wheel.

 **NOTE:** The Nissan is a front wheel drive vehicle, hence the larger wheel lock-up values; see Table 5-1.

Finally, noting the vehicle rotated and skidded after impact, let's select that EDCRASH option:

- Click on the *Rot/Lat Skid* check box.
- Press *OK* to accept the wheel data for the Nissan Sentra.

The wheel data have now been assigned for the Nissan Sentra.

Let's conclude event set-up for the Nissan Sentra by supplying a damage profile:

- Choose *Set-up* from the menu bar, select *Damage Profiles*. The Damage Profile dialog is displayed for the Nissan Sentra.

The Damage Profile dialog initially contains *None*, waiting for us to assign a CDC (Collision Deformation Classification):

- Replace *None* in the CDC field with 02RPEW3 and click *Apply*. The default damage profile is displayed according to the CDC.

Because we actually measured the damage profile during our vehicle inspection, let's enter the measured width, depth and offset:

- Enter the right side damage width, 220 cm, and offset, -40 cm.

We measured five crush depths along the right side of the Nissan, so we have four crush zones:

- Click on the Damage Profile *Zones* option list and change the default value from 3 to 4.


Table 5-3 Crush depths for the right side of the Nissan Sentra 4-Dr.

Crush Depth No.	Crush Depth (cm)
1	20.0
2	30.0
3	50.0
4	45.0
5	10.0

NOTE: Crush depths are entered rear-to-front.

- Enter the five crush depths along the right side, according to Table 5-3 (remember to press *Apply* after entering all of the values).

The damage profile appears as shown in Figure 5-11. Note the reported force is 506,798 Newtons. Further, note the force reported for the Ford Escort is 726,647 Newtons. According to Newton's 3rd Law, the forces on both vehicles should be equal.

 NOTE: It is quite common for the initially computed forces to be different when side impact is involved because a vehicle's side stiffness varies according to where it was impacted; the wheels are much stiffer than other locations.

The best way to solve this problem is to adjust the stiffness coefficients to equalize the forces. If the damage profile has uniform stiffness, we can quickly estimate the amount of the adjustment by noting the current ratio of the calculated collision forces:

$$\text{force ratio} \quad \frac{F_{\text{Escort}}}{F_{\text{Sentra}}} \quad \frac{726,647}{506,798} \quad 1.43$$

But the side of the Nissan *does not* have a uniform stiffness, and a large portion of the impact force was applied at the right rear wheel. Therefore, we cannot directly use the above method. Let's adjust the stiffness by increasing the A and B coefficients for zone 1, the zone that includes the right rear wheel, using trial and error.





Figure 5-11 Damage Profile dialog for the Nissan Sentra.

 **NOTE:** The A and B stiffness coefficients are related; when adjusting the stiffness coefficients, always multiply A and B by the same factor!

Let's try a factor of 2.0:

- Click *A Stiffness*. The A Stiffness Coefficients dialog is displayed (see Figure 5-12) with the default value, 245 N/cm.

The adjusted value for our first attempt is 490 (245 x 2).

- Enter 490.0 for Zone 1.
- Press *OK* to accept the new value.




Figure 5-12 A Stiffness and B Stiffness coefficients dialogs.

Now, let's adjust the B value:

- Click *B Stiffness*. The B Stiffness Coefficients dialog is displayed (see Figure 5-12) with the default value, 50 N/cm².

The adjusted value for our first attempt is 100.0 (50 x 2).

- Enter 100.0 for Zone 1.
- Press *OK* to accept the new value.

Now, note the current peak force displayed in the Damage Profile dialog. The value is quite a bit too low (again, we want it to equal the value of 726,647 Newtons for the Ford Escort). Try a factor of 5:

- Click *A Stiffness* to display the A Stiffness Coefficients dialog, and enter 1225 (245 x 5). Press *OK* to remove the dialog.
- Click *B Stiffness* to display the B Stiffness Coefficients dialog, and enter 250 (50 x 5). Press *OK* to remove the dialog.

Now the force for the Nissan is quite a bit greater than the force on the Ford. Repeat the process using a factor of 3.4:

- Click *A Stiffness* to display the A Stiffness Coefficients dialog, and enter 833 (245 x 3.4). Press *OK* to remove the dialog.
- Click *B Stiffness* to display the B Stiffness Coefficients dialog, and enter 170 (50 x 3.4). Press *OK* to remove the dialog.

The resulting force on the Nissan is 734,667 Newtons, closely matching the force on the Ford Escort.

- Press *OK* to accept the assigned the damage profile.

It is always a good idea to make sure that the entered impact positions and PDOFs conform to Newton's 3rd Law. According to Newton's 3rd Law, the vehicles' PDOFs must be equal and *opposite*. When we apply this constraint to our data, we find the following condition must be satisfied:

$$PDOF_1 - \Psi_1 = PDOF_2 - \Psi_2 \pm 180$$

where:


$$\Psi = \text{heading angle}$$

Solving for $PDOF_2$, we have:

$$\begin{aligned} PDOF_2 &= PDOF_1 + \Psi_1 + \Psi_2 \pm 180 \\ &= -30 + 195 - (-90) \pm 180 \\ &= 75 \text{ deg} \end{aligned}$$

But we assigned a CDC of 02RPEW3, which has a default PDOF of 60 degrees. Our calculation above shows that to satisfy Newton's 3rd law, we must change the PDOF to 75 degrees. In this event, the PDOFs are not opposite. Therefore, we will edit the PDOF:

- In the *PDOF* field, replace 60 with 75.
- Click *Apply* to accept the change.

 **NOTE:** If you click on *Use Newton's 3rd Law*, EDCRASH will make this calculation for you automatically!

Due to the effect of the energy magnification factor, the above change to the PDOF will change the peak force calculated for the Nissan Sentra. The peak force is now 658,684 N for the Nissan Sentra. By comparing this force with the peak force on the Ford Escort, 726,647 N, we find the difference is acceptable, so we are finished setting up the event.

- Press OK to accept the assigned damage profile.

Before we execute the event, let's set up the Key Results windows:


- If Key Results windows are not displayed, choose *Show Key Results* from the Options menu.
- Drag the Key Results windows to a convenient location, where they do not block the view but still allow us access to the viewer thumb wheel controls (in case we want to change the view).

Now we're ready to execute the event. The viewer should appear as shown in Figure 5-13. Take a moment to set the view using the viewer controls or Set Camera dialog.

Now, let's execute the EDCRASH event.

- Using the Event Controller, press *Play* to execute the event.

Although nothing appears to happen (i.e., the vehicles don't move), the event has been executed. Unlike simulation calculations, which are repetitive, reconstruction calculations are executed only once, and thus, happen very quickly.

 **NOTE:** You may confirm that execution has occurred by checking the results in your Key Results windows.

We have now completed the event.




Figure 5-13 EDCRASH Tutorial event after execution. The Key Results windows show the pre-impact speeds, delta-Vs, and other key information from the analysis.

TUTORIAL

Viewing Results

Now that we have produced our EDCRASH simulations, let's take a detailed look at the results. The Playback Editor is used for reviewing and printing reports for each event in the current case, as well as for producing video output.

EDCRASH produces the following reports:

- **Accident History** - A table of user-entered positions and their respective (calculated) velocities
- **Damage Data** - A table of damage profile coordinates, CDC, PDOF and Delta-V for each vehicle
- **Damage Profiles** - A plan view of the vehicles showing their damage profiles (damage width, depth and midpoint offset)
- **Event Data** - A table of scene data (positions, orientations and velocities)
- **Messages** - A list of messages produced by the current run
- **Momentum Diagrams (Scene and Damage)** - A vector diagram showing the pre-impact and post-impact momentum vectors for each vehicle. The scene-based diagram uses impact velocity calculated from the momentum-based delta-V; the damage-based diagram uses the impact velocity calculated from the damage-based delta-V.
- **Program Data** - A table containing program control information
- **Site Drawing** - A static perspective view of the accident site showing the vehicles at their user-entered positions
- **Vehicle Data** - A series of tables containing the vehicle data used by EDCRASH

To view the output reports, we need to be in Playback mode:

- Choose *Playback Mode*. The Playback Editor is displayed.

Report Windows

The reports listed on the previous page are displayed by selecting Preview Windows. Each Report Window contains an individual report.




Figure 5-14 Report Window Information dialog, showing the name of the event(s) in the current case.

To view the reports produced by the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed, as shown in Figure 5-14, and includes a list of the active events (*EDCRASH, Visibility Study* is the only event in this tutorial). The Report Window Information dialog also includes the user-editable *Report Window Name* text field and *Selected Output* option list.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose any of the available reports.
- Press *OK* to display the report.

The selected report will be displayed in a resizable window. The following pages illustrate the reports produced for the *EDCRASH, Visibility Study* event.

Accident History

The EDCRASH Accident History report is the primary output from EDCRASH. This report summarizes the key results for each vehicle, including impact velocity, delta-V for each available calculation method (*Damage* and *Linear Momentum*), separation velocity and relative velocity at impact.

ACCIDENT HISTORY				
BEGIN BRAKING VELOCITY (Basis: Scene Data)				
	Total	Forward	Lateral	Sideslip
	(km/h)	(km/h)	(km/h)	(deg)
Ford Escort 2-Dr Hatchback	54.4	54.4	0.0	0.0
IMPACT VELOCITY (Basis: Scene Data and Linear Momentum)				
	Total	Forward	Lateral	Sideslip
	(km/h)	(km/h)	(km/h)	(deg)
Ford Escort 2-Dr Hatchback	27.5	27.4	-2.1	-4.4
Nissan Sentra 4-Dr	35.8	35.8	0.0	0.0
DELTA-V (Basis: Damage)				
	Total	Forward	Lateral	PDof
	(km/h)	(km/h)	(km/h)	(deg)
Ford Escort 2-Dr Hatchback	57.7	-52.3	24.4	-25.0
Nissan Sentra 4-Dr	56.5	-9.8	-55.6	80.0
DELTA-V (Basis: Linear Momentum)				
	Total	Forward	Lateral	PDof
	(km/h)	(km/h)	(km/h)	(deg)
Ford Escort 2-Dr Hatchback	11.7	-10.5	5.3	-26.9
Nissan Sentra 4-Dr	11.5	-2.4	-11.2	78.1
SEPARATION VELOCITY (Basis: Scene Data)				
	Total	Forward	Lateral	Angular
	(km/h)	(km/h)	(km/h)	(deg/sec)
Ford Escort 2-Dr Hatchback	17.2	16.9	3.2	55.1
Nissan Sentra 4-Dr	35.3	33.5	-11.2	119.1
RELATIVE VELOCITY DATA				
Closing Velocity (km/h):			37.6	
Restitution:			0.089	

Figure 5-15 Accident History Report for EDCRASH, Visibility Study event.


To view the Accident History report for the EDCRASH, Visibility Study event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Accident History*.
- Press *OK*.

The Accident History report is displayed for the EDCRASH, Visibility Study event, as shown in Figure 5-15.

Damage Data

The Damage Data report provides the user-entered damage profile and other event-related damage data for the current EDCRASH event.



	Ford Escort 2-Dr Hat	Nissan Sentra 4-Dr
CDC:	11fdew3	02rpew3
PDof (deg):	-25.00	80.00
Damage Width (cm):	169.42	220.00
Crush Depths -		
C1 (cm):	75.00	20.00
C2 (cm):	60.00	30.00
C3 (cm):	50.00	50.00
C4 (cm):	45.00	45.00
C5 (cm):	40.00	10.00
C6 (cm):	40.00	
C7 (cm):	45.00	
Damage Midpoint Offset (cm):	0.00	-40.00
Damage Energy (Joule):	217306.50	127201.07
Peak Force (N):	694350.38	642315.22
Moment Arm Of PDof (cm):	49.14	65.75
Impulse Center (cm) x:	152.07	-54.89
y:	-16.69	67.33

Figure 5-16 Damage Data Report for EDCRASH, Visibility Study event.

To view the Damage Data report for the EDCRASH, Visibility Study event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Damage Data*.
- Press *OK*.

A portion of the Damage Data report is displayed for EDCRASH, Visibility Study is shown in Figure 5-16.

Damage Profiles

The Damage Profiles report provides a visual representation of the user-entered damage profile and PDOF for the current EDCRASH event.




Figure 5-17 Damage Profiles Report for *EDCRASH, Visibility Study* event.


Let's display the Damage Profiles report for this event. To view the Damage Profiles report for the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Damage Profiles*.
- Press *OK*.

The Damage Profiles report is displayed for the *EDCRASH, Visibility Study* event (see Figure 5-17).

Event Data

The EDCRASH Event Data report includes all the scene data used for the current EDCRASH event. This scene data also provides the total amount and direction of rotation (clockwise vs counter-clockwise).



	Ford Escort 2-Dr Hat	Nissan Sentra 4-Dr
SCENE INFORMATION		
Begin Braking, X (m):	18.00	
Begin Braking, Y (m):	15.00	
Begin Braking, Heading (deg):	180.00	
Impact, X (m):	6.00	3.50
Impact, Y (m):	13.75	13.00
Impact, Heading (deg):	195.00	-90.00
Impact Ang Vel (deg/sec):	0.00	0.00
Impact Sideslip Angle (deg):	-4.35	0.00
Separation, X (m):	6.00	3.50
Separation, Y (m):	13.75	13.00
Separation, Heading (deg):	195.00	-90.00
Separation Angle (deg):	205.77	-108.56
Separation, Vtotal (km/h):	17.23	35.30
Separation, Fwd Vel (km/h):	16.92	33.46
Separation, Lat Vel (km/h):	3.22	-11.23
Separation, Ang Vel (deg/sec):	55.09	119.06
Final/Rest, X (m):	3.50	0.50
Final/Rest, Y (m):	12.75	2.25
Final/Rest, Heading (deg):	230.00	70.00
Final/Rest, Vtotal (km/h):	0.00	0.00
Rot/Lat Skid:	Yes	Yes
Impact-to-rest Rotation (deg):	35.00	160.00
Rotation Direction:	Clockwise	Clockwise

Figure 5-18 Event Data Report for *EDCRASH, Visibility Study* event.

To view the Event Data report for the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Event Data*.
- Press *OK*.

The Event Data report is displayed for the *EDCRASH, Visibility Study* event, as shown in Figure 5-18.

Messages

The Messages report produced by EDCRASH is one of its most important reports. While simulation programs typically produce very few messages, a reconstruction program has the opportunity to evaluate the consistency of the user-entered scene and damage measurements. Careful review of these messages may show inconsistencies; correcting these inconsistencies may lead to improved results.




Figure 5-19 Messages Report for *EDCRASH, Visibility Study* event.

To view the Message report produced by the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Messages*.
- Press *OK*.

The Messages report is displayed for the *EDCRASH, Visibility Study* event, as shown in Figure 5-19.

Momentum Diagrams




Figure 5-20 Momentum Diagram Report for *EDCRASH, Visibility Study* event.

Let's display a Momentum Diagram report for this event. To view the Momentum Diagram, Scene Data, report for the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Momentum Diagram, Scene*.
- Press *OK*.

The Momentum Diagram report based on the scene data is displayed for the *EDCRASH, Visibility Study* event (see Figure 5-20).

Program Data

The EDCRASH Program Data report lists the physics program, in this case EDCRASH, and physics program version number. It also contains parameters used when the Trajectory Simulation option is selected and consistency checks within EDCRASH.




Figure 5-21 Program Data Report for *EDCRASH, Visibility Study* event.

To view the Program Data report for the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Program Data*.
- Press *OK*.

The Program Data report is displayed for the *EDCRASH, Visibility Study* event, as shown in Figure 5-21.

Site Drawing

The Site Drawing is a static display of the event with the vehicles at their user-entered path positions (Begin Braking, Impact, Point-on-curve, End-of-rotation and Rest).



Figure 5-22 Site Drawing Report for *EDCRASH, Visibility Study* event showing both vehicles at each user-entered position.

Let's display a Site Drawing for this event. To view the Site Drawing, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Site Drawing*.
- Press *OK*.

The Site Drawing viewer is displayed for the *EDCRASH, Visibility Study* event (see Figure 5-22). The vehicles are shown at each user-entered position.

Vehicle Data

The Vehicle Data report provides the physical data used by EDCRASH, including dimensions, inertias, tire properties, wheel lock-ups and stiffness coefficients.


VEHICLE DATA			
	Ford Escort 2-Dr Hat	Nissan Sentra 4-Dr	
CG To Front Axle (cm):	93.22	91.69	
CG To Rear Axle (cm):	156.72	162.31	
Track Width (cm):	143.51	144.93	
Yaw Inertia (kg-m ²):	1494.11	1902.78	
Mass (kg):	1124.55	1149.52	
Weight (N):	11031.87	11276.76	
Body Length To Front (cm):	178.56	173.99	
Body Length To Rear (cm):	-252.09	-252.73	
Body Width Overall (cm):	169.42	171.44	
Crush Stiffness, Zone 1 -			
A (lb/in):	224.00	476.00	
B (lb/in ²):	98.00	245.00	
Crush Stiffness, Zone 2 -			
A (lb/in):	224.00	140.00	
B (lb/in ²):	98.00	72.00	
Crush Stiffness, Zone 3 -			
A (lb/in):	224.00	140.00	
B (lb/in ²):	98.00	72.00	
Crush Stiffness, Zone 4 -			
A (lb/in):	224.00	140.00	
B (lb/in ²):	98.00	72.00	
Crush Stiffness, Zone 5 -			
A (lb/in):	224.00		
B (lb/in ²):	98.00		
Crush Stiffness, Zone 6 -			
A (lb/in):	224.00		
B (lb/in ²):	98.00		
TIRE DATA			
Tire Data, Axle 1 (right) -			
Slide Mu (*):	0.72	0.74	
Cornering Stiffness (N/deg):	-765.10	-504.01	
Lockup (%/100):	1.00	0.20	
Tire Data, Axle 1 (left) -			
Slide Mu (*):	0.72	0.74	
Cornering Stiffness (N/deg):	-765.10	-504.01	
Lockup (%/100):	1.00	0.20	
Tire Data, Axle 2 (right) -			
Slide Mu (*):	0.72	0.74	
Cornering Stiffness (N/deg):	-765.10	-504.01	
Lockup (%/100):	0.01	0.01	
Tire Data, Axle 2 (left) -			

Figure 5-23 Vehicle Data Report for EDCRASH, Visibility Study event.

To view the Vehicle Data report for the *EDCRASH, Visibility Study* event, perform the following steps:

- Click *Add New Object*. The Report Window Information dialog is displayed.
- Select *EDCRASH, Visibility Study* from the Active Events list.
- Click on the *Selected Output* option list and choose *Vehicle Data*.
- Press *OK*.


A portion of the Vehicle Data report is displayed for *EDCRASH, Visibility Study* is shown in Figure 5-23.

 **NOTE:** *The Vehicle Data and several other reports contain more information than fits into the default window size. Use the scroll bars or resize the dialog to view the entire report.*

Printing


The final step is to print the above reports. Printing reports is simple. All you do is choose a report and print it. For example:


- Click on the dialog header of the *Accident History - EDCRASH, Visibility Study* report. Your selection is highlighted and the Accident History window pops to the top of the display (if it isn't there already), indicating it is the current window.
- Click on the *File* menu and choose *Print*. The Print dialog is displayed, allowing the user to select from several available print options.


 **NOTE:** Alternatively, you can click on the print icon in the upper menu bar.

- Press *OK*. The Accident History output report is printed on the system printer.

That's all there is to it! You can print any other report using the same two steps described above.

 **NOTE:** The Print dialog provides several options. Refer to your Windows or printer manual for more information.

 **NOTE:** For several reports it may be best to print in landscape rather than portrait mode.

 **NOTE:** The font size of both the printed reports and screen display may be edited by clicking on the Options menu and choosing Preferences. Use the Font Size option list to change the size.